

STEP 1: Hook the front of the top connector to the outside edge of the top rail and align with the center of the vertical cap.



DO NOT HOOK THE BACK OF THE TOP CONNECTOR FIRST AND TRY TO SNAP OVER THE TOP RAIL. THE FRONT TABS OF THE TOP CONNECTOR WILL BREAK.

STEP 2: Press down on the back edge of the top connector to snap down over the top rail.

